Okayo WT-350

System for guided tours

INSTRUCTIONS FOR USE (short)



- The transmitter (grey) and receivers (black) can be switched on and off by pressing and holding the button at the top of the device for 2 seconds.
- The microphone jack should be inserted in the socket with the microphone symbol at the top of the transmitter while the earphones jack should be inserted in the socket with the earphones symbol in the receiver.
- After switching the receiver and transmitter on you have 2 seconds to begin selecting a channel in the range 1-16 using the + and - buttons. If you have not started to select the channel two seconds after switching the device on then the channels will be automatically locked (padlock symbol in the top left corner of the screen).
- To unlock them press both the + and - buttons at the same time. Hold them together for 1 second.
- The volume on the receivers can be changed once the channels are locked by pressing + and -.
- The transmitter has a mute function which can be switched on and off by pressing the button at the top of the device once quickly (the same button used for switching the device on and off).
- In order to save the battery, if there is no signal from the transmitter for 20 minutes the receivers will automatically switch off and if the earphones are not connected for 20 seconds the receivers switch to standby mode preventing change of volume for example.
- With the WT-350 model it is possible to synchronise the channel on the receivers with the channel on the transmitter. To do this you should simultaneously hold the + and - buttons for 5 seconds. The LED at the top of the device will start to flash orange. You should then point the transmitter (like a TV remote) at the switched-on receivers from a distance of no more than 1.5 metres. You then need to switch the receivers off and when you switch them back on again they will be tuned to the channel of the transmitter.

ATTENTION

Never use more than one transmitter on the same channel at the same time, i.e. when there are 2 groups in the same place if one transmitter is on channel 1 then the second transmitter should be for example on channel 3.

In the case **that the receiver is not working** (no sound coming through the earphones) you should check that:

- the receiver is on the same channel as the transmitter,
- the headphone jack is fully inserted in the receiver,
- the battery is correctly inserted.

If the receiver still does not work you should switch it off and then back on, with the headphone jack inserted in the receiver while doing so.

If the transmitter is switched off then the receivers will also switch off after 20 minutes (to prevent the receiver battery running out when users forget to switch them off).

Twenty seconds after the earphones are unplugged the receiver switches to standby mode to limit battery consumption.

If you have any questions please contact us on +48 58 550 10 25 or +48 696 257 665